



## CODING TABLE

SID RNAV BUTOB 1A RWY 18					RECIFE / Guarapes - Gilberto Freyre, INTL (SBRF)							SBRF_SID_01W		15 MAY 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N/A	N/A	N/A	CA	183.13° Mag 161.79° True	N/A	N/A	+1500	N/A	N/A	N/A	2.86	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	BUTOB	DF	N/A	R	-6000	N/A	N/A	N/A	N/A	2.86	OTHER	RNAV 1 or RNP 1
10	KUKES	N/A	N/A	BUTOB	IF	N/A	N/A	-6000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	KUKES	N	N/A	KUKES	TF	271.69° Mag 250.26° True	N/A	N/A	N/A	N/A	N/A	132.61	N/A	OTHER	RNAV 1 or RNP 1
10	IROSI	N/A	N/A	BUTOB	IF	N/A	N/A	-6000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	IROSI	N	N/A	RF129	TF	8.29° Mag 346.86° True	N/A	N/A	+9000	N/A	N/A	16.94	N/A	OTHER	RNAV 1 or RNP 1
30	IROSI	N	N/A	RF131	TF	8.22° Mag 346.87° True	N/A	N/A	+12000	N/A	N/A	9.84	N/A	OTHER	RNAV 1 or RNP 1
40	IROSI	N	N/A	RF132	TF	8.19° Mag 346.90° True	N/A	N/A	N/A	N/A	N/A	13.55	N/A	OTHER	RNAV 1 or RNP 1
50	IROSI	N	N/A	IROSI	TF	333.89° Mag 312.67° True	N/A	N/A	N/A	N/A	N/A	16.88	N/A	OTHER	RNAV 1 or RNP 1
10	GAVAK	N/A	N/A	BUTOB	IF	N/A	N/A	-6000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	GAVAK	N	N/A	UDOSA	TF	252.58° Mag 231.15° True	N/A	N/A	N/A	N/A	N/A	73.96	N/A	OTHER	RNAV 1 or RNP 1
30	GAVAK	N	N/A	GAVAK	TF	251.89° Mag 230.03° True	N/A	N/A	N/A	N/A	N/A	78.24	N/A	OTHER	RNAV 1 or RNP 1
10	UDOSA	N/A	N/A	BUTOB	IF	N/A	N/A	-6000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	UDOSA	N	N/A	UDOSA	TF	252.58° Mag 231.15° True	N/A	N/A	N/A	N/A	N/A	73.96	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
BUTOB	S 08:16:05.50W 35:09:38.20
KUKES	S 09:00:45.34W 37:15:46.22
RF129	S 07:59:31.24W 35:13:30.96
RF131	S 07:49:53.82W 35:15:46.00
RF132	S 07:36:38.26W 35:18:51.54
IROSI	S 07:25:08.21W 35:31:21.32
UDOSA	S 09:02:37.65W 36:07:50.87
GAVAK	S 09:53:02.05W 37:08:35.85

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
18	S 08:08:20.78 W 34:55:08.34	32.31

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT