



CODING TABLE

IAC VOR X RWY14					FLORIANÓPOLIS / Hercílio Luz, INTL (SBFL)							SBFL_IAC_02L		02 NOV 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	FLN	MUKAL	IF	N/A	N/A	N/A	+5100	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	FLN	ILTUM	CF	140.79° Mag / 120.86° True	N/A	N/A	+3000	N/A	N/A	6.01	N/A	IF	N/A
10	APCH	N/A	FLN	DIMOG	IF	N/A	N/A	N/A	+5000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	FLN	FL959*	AF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	FLN	ILTUM	CF	140.79° Mag / 120.86° True	N/A	N/A	+3000	N/A	N/A	1.54	N/A	IF	N/A
10	APCH	N/A	FLN	ILRUK	IF	N/A	N/A	N/A	+5700	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	FLN	FL958*	AF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	FLN	ILTUM	CF	140.79° Mag / 120.86° True	N/A	N/A	+3000	N/A	N/A	1.61	N/A	IF	N/A
10	FINAL	N/A	FLN	ILTUM	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	FLN	KUDIL	CF	140.79° Mag / 120.86° True	N/A	N/A	+2200	N/A	N/A	2.25	N/A	OTHER	N/A
30	FINAL	N/A	FLN	KOSDA	CF	140.79° Mag / 120.86° True	N/A	N/A	R2010	N/A	N/A	2.37	N/A	FAF	N/A
40	FINAL	N/A	FLN	FL964*	CF	140.79° Mag / 120.86° True	N/A	N/A	R1450	N/A	N/A	1.54	-3.40	SDF	N/A
50	FINAL	N/A	FLN	FLN14*	CF	140.80° Mag / 120.87° True	N/A	N/A	@66	N/A	N/A	3.84	-3.40	FTP	N/A
10	MA	N/A	FLN	MATSA	CF	141.39° Mag / 121.47° True	N/A	N/A	+4000	N/A	N/A	16.62	N/A	MAHF	N/A
20	MA	N/A	FLN	MATSA	HM	321.39° Mag / 301.47°	R	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	N/A

* Fictitious point only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MUKAL	S 27:31:37.38W 48:48:29.26
ILRUK	S 27:39:53.67W 48:46:11.97
DIMOG	S 27:29:36.03W 48:39:12.38
FL958*	S 27:33:53.66W 48:44:14.51
FL959*	S 27:33:55.83W 48:44:10.45
ILTUM	S 27:34:43.56W 48:42:41.12
KUDIL	S 27:35:53.25W 48:40:30.61
KOSDA	S 27:37:06.39W 48:38:13.52
FL964*	S 27:37:53.90W 48:36:44.40
FLN14*	S 27:39:52.58W 48:33:01.55
MATSA	S 27:48:52.80W 48:16:26.40

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT