



## CODING TABLE

STAR RNAV ENTIV 1A RWY 18					RECIFE / Guararapes - Gilberto Freyre, INTL (SBRF)							SBRF_STAR_010		25 JAN 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of The Fix	Navigation Specification
10	ENTIV	N/A	N/A	ENTIV	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV1 or RNP 1
20	ENTIV	N	N/A	RF098	TF	63.46° Mag 41.71° True	N/A	N/A	N/A	N/A	N/A	33.86	N/A	OTHER	RNAV1 or RNP 1
30	ENTIV	N	N/A	RF066	TF	58.34° Mag 36.80° True	N/A	N/A	+9000	N/A	N/A	8.75	N/A	OTHER	RNAV1 or RNP 1
40	ENTIV	N	N/A	RF067	TF	46.08° Mag 24.60° True	N/A	N/A	+7000	N/A	N/A	9.06	N/A	OTHER	RNAV1 or RNP 1
50	ENTIV	N	N/A	RF068	TF	46.00° Mag 24.58° True	N/A	N/A	+6000	N/A	N/A	3.93	N/A	OTHER	RNAV1 or RNP 1
60	ENTIV	N	N/A	RF009	TF	2.35° Mag 340.96° True	N/A	N/A	+3000	N/A	N/A	9.56	N/A	IAF	RNAV1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
ENTIV	S 08:48:47.39W 35:23:21.89
RF098	S 08:23:23.05W 35:00:38.28
RF066	S 08:16:20.56W 34:55:20.96
RF067	S 08:08:03.93W 34:51:32.78
RF068	S 08:04:28.52W 34:49:53.90
RF009	S 07:55:24.00W 34:53:02.40

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT