

[illegible]

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR GNV	S 16:38:27.00W 49:12:40.00
VOR ULD	S 18:52:35.80W 48:13:16.68
NDB CAL	S 17:43:28.76W 48:36:37.48
GIDVO	S 18:26:25.20W 49:13:07.80
GUARI	S 18:34:43.80W 48:21:58.80
SATNA	S 16:59:15.60W 48:54:42.00
OPRAX	S 16:44:31.80W 48:17:56.40
ROMIK	S 17:13:13.20W 48:43:07.80

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
09	S 17:43:16.74 W 48:35:50.11	2246