



CODING TABLE

SID RNAV BOBAV 2A RWY 13					FORTALEZA / Pinto Martins, INTL (SBFZ)							SBFZ_SID_00R	08 AUG 24		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	BOBAV	N	N/A	KUGUS	CF	125.50° Mag / 104.92° True	N/A	N/A	N/A	N/A	N/A	13.26	N/A	OTHER	RNAV 1 or RNP 1
20	BOBAV	N	N/A	BOBAV	TF	153.64° Mag / 132.60° True	N/A	N/A	N/A	N/A	N/A	26.08	N/A	OTHER	RNAV 1 or RNP 1

SID RNAV BOBAV 2A RWY 31					FORTALEZA / Pinto Martins, INTL (SBFZ)							SBFZ_SID_00R	08 AUG 24		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	BOBAV	N	N/A	N/A	CA	305.97° Mag / 284.92° True	N/A	N/A	+1000	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	BOBAV	N	N/A	UMBAR	DF	N/A	R	N/A	+8000	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	BOBAV	N	N/A	KUGUS	TF	174.48° Mag / 153.46° True	N/A	N/A	N/A	N/A	N/A	6.63	N/A	OTHER	RNAV 1 or RNP 1
40	BOBAV	N	N/A	BOBAV	TF	153.64° Mag / 132.60° True	N/A	N/A	N/A	N/A	N/A	26.08	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
KUGUS	S 03:50:19.80W 38:18:24.00
BOBAV	S 04:08:03.67W 37:59:11.39
UMBAR	S 03:44:22.31W 38:21:21.79

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (ft)
13	S 03:46:47.13 W 38:31:10.99	65.00
31	S 03:46:22.85 W 38:32:41.72	81.69

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT