



## CODING TABLE

IAC NDB Z RWY 06					ITAITUBA / Itaituba (SBIH)							SBIH_IAC_00B		14 JUL 22	
Seq Num	IAP Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of TheFix	Navigation Specification
10	FINAL	N/A	N/A	YUB	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	YUB	YUB	FC	245.27° Mag 227.17° True	N/A	N/A	+1600	210	-	2.33 min	N/A	OTHER	N/A
30	FINAL	N/A	YUB	YUB02*	CF	44.00° Mag 25.91° True	L	N/A	@142	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	N/A	N/A	CA	44.00° Mag 25.91° True	N/A	N/A	+1500	210	-	N/A	N/A	N/A	N/A
20	MA	N/A	N/A	YUB	DF	N/A	R	N/A	+3000	210	-	N/A	N/A	MAHF	N/A
30	MA	N/A	YUB	YUB	HM	245.27° Mag 227.17° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

\*Fictitious point for coding purposes only.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB YUB	S 04:14:25.80W 56:00:16.80
YUB02	S 04:14:47.27W 56:00:27.19

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT