



CODING TABLE

IAC ILS X or LOC X RWY 16L					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_001		24 FEB 22	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	NTL	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	NTL	FC	359.63° Mag / 338.32° True	L	N/A	+2200	190	-	8.02	N/A	OTHER	N/A
30	APCH	N/A	NTL	CASTO	CF	162.19° Mag / 140.88° True	N/A	N/A	+2200	N/A	N/A	N/A	N/A	IF	N/A
10	FINAL	N/A	N/A	CASTO	IF	N/A	N/A	N/A	+2200	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	INT	NIPKA	CF	162.19° Mag / 140.88° True	N/A	N/A	R1570	N/A	N/A	3.30	N/A	FAF	N/A
30	FINAL	Y	INT	RW16L	CF	162.19° Mag / 140.88° True	N/A	N/A	@199	N/A	N/A	4.29	-3.00	LTP	N/A
10	MA	N/A	N/A	N/A	VA	162.20° Mag / 140.90° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	NTL	DF	N/A	R	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	Y	NTL	NTL	HM	359.62° Mag / 338.32° True	L	N/A	+4000	N/A	N/A	1.00 min	N/A	MAHF	N/A

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME NTL	S 05:54:30.00W 35:14:55.20
CASTO	S 05:48:11.04W 35:19:53.13
NIPKA	S 05:50:46.20W 35:17:48.60
RW16L	S 05:54:06.61W 35:15:05.70
INT	S 05:55:17.40W 35:14:08.40

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT