



CODING TABLE

STAR RNAV ORESU 2C RWY 12					SÃO ROQUE / São Paulo Catarina Aeroporto Executivo, INTL (SBJH)							SBJH_STAR_00E		19 FEB 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	UTLOT	N/A	N/A	UTLOT	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	UTLOT	N	N/A	RUSTE	TF	150.68° Mag / 129.01° True	N/A	B24000	B20000	N/A	N/A	27.99	N/A	OTHER	RNAV 1 or RNP 1
30	UTLOT	N	N/A	ORESUS	TF	150.63° Mag / 128.85° True	N/A	B17000	B13000	N/A	N/A	24.47	N/A	OTHER	RNAV 1 or RNP 1
10	ENTIT	N/A	N/A	ENTIT	IF	N/A	N/A	-27000	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ENTIT	N	N/A	OTAGA	TF	245.26° Mag / 223.11° True	N/A	N/A	N/A	N/A	N/A	5.96	N/A	OTHER	RNAV 1 or RNP 1
30	ENTIT	N	N/A	NEKIG	TF	245.25° Mag / 223.13° True	N/A	-23000	N/A	N/A	N/A	5.15	N/A	OTHER	RNAV 1 or RNP 1
40	ENTIT	N	N/A	MAVKA	TF	245.28° Mag / 223.20° True	N/A	N/A	N/A	N/A	N/A	10.07	N/A	OTHER	RNAV 1 or RNP 1
50	ENTIT	N	N/A	EVMOL	TF	234.30° Mag / 212.28° True	N/A	N/A	+20000	N/A	N/A	12.62	N/A	OTHER	RNAV 1 or RNP 1
60	ENTIT	N	N/A	ORESUS	TF	234.04° Mag / 212.10° True	N/A	B17000	B13000	N/A	N/A	12.01	N/A	OTHER	RNAV 1 or RNP 1
10	RWY	N/A	N/A	ORESUS	IF	N/A	N/A	B17000	B13000	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	PRUMO	TF	190.37° Mag / 168.50° True	N/A	N/A	+12000	N/A	N/A	13.94	N/A	OTHER	RNAV 1 or RNP 1
30	RWY	N	N/A	JH033	TF	218.34° Mag / 196.49° True	N/A	B10000	B9000	N/A	N/A	5.63	N/A	OTHER	RNAV 1 or RNP 1
40	RWY	N	N/A	JH034	TF	294.04° Mag / 272.21° True	N/A	-7000	N/A	N/A	N/A	6.20	N/A	OTHER	RNAV 1 or RNP 1
50	RWY	N	N/A	JH004	TF	294.04° Mag / 272.25° True	N/A	N/A	@5500	N/A	N/A	5.44	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
UTLOT	S 22:28:26.40W 47:53:32.40
RUSTE	S 22:46:05.29W 47:30:00.43
ENTIT	S 22:25:03.04W 46:39:28.71
OTAGA	S 22:29:24.97W 46:43:52.60
NEKIG	S 22:33:11.27W 46:47:40.90
MAVKA	S 22:40:32.93W 46:55:07.95
EVMOL	S 22:51:15.37W 47:02:25.92
ORESU	S 23:01:27.85W 47:09:21.08
PRUMO	S 23:15:10.10W 47:06:19.99
JH033	S 23:20:35.26W 47:08:04.23
JH034	S 23:20:20.69W 47:14:48.44
JH004	S 23:20:07.70W 47:20:42.93

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT.