



CODING TABLE

SID RNAV GATUL 1A RWY 12					ARACAJU / Santa Maria, INTL (SBAR)							SBAR_SID_00J		30 DEC 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	N/A	N/A	N/A	CA	114.98° Mag 91.94° True	N/A	N/A	+1500	N/A	N/A	N/A	2.29	OTHER	RNP 1 or RNAV 1
20	RWY	N	N/A	GATUL	DF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
10	ESLIB	N/A	N/A	GATUL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	ESLIB	N	N/A	AR001	TF	211.09° Mag 187.87° True	N/A	N/A	N/A	N/A	N/A	30.00	N/A	OTHER	RNP 1 or RNAV 1
30	ESLIB	N	N/A	ESLIB	TF	211.46° Mag 187.91° True	N/A	N/A	N/A	N/A	N/A	86.56	N/A	OTHER	RNP 1 or RNAV 1
10	RAXOT	N/A	N/A	GATUL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	RAXOT	N	N/A	AR001	TF	211.09 Mag 187.87° True	N/A	N/A	N/A	N/A	N/A	30.00	N/A	OTHER	RNP 1 or RNAV 1
30	RAXOT	N	N/A	RAXOT	TF	220.86° Mag 197.50° True	N/A	N/A	N/A	N/A	N/A	35.49	N/A	OTHER	RNP 1 or RNAV 1
10	ATARO	N/A	N/A	GATUL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	ATARO	N	N/A	ATARO	TF	235.07° Mag 211.76° True	N/A	N/A	N/A	N/A	N/A	61.80	N/A	OTHER	RNP 1 or RNAV 1
10	DAMAV	N/A	N/A	GATUL	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNP 1 or RNAV 1
20	DAMAV	N	N/A	DAMAV	TF	277.55° Mag 254.41° True	N/A	N/A	N/A	N/A	N/A	40.11	N/A	OTHER	RNP 1 or RNAV 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
AR001	S11:39:05.62 W 037:04:05.02
ATARO	S12:02:05.68 W 037:33:00.96
DAMAV	S11:20:06.89 W 037:39:12.68
ESLIB	S13:05:13.20 W 037:16:13.20
GATUL	S11:09:14.40 W 036:59:54.43
RAXOT	S12:13:05.61 W 037:14:57.58

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
12	S 10:59:03.72 W 37:03:37.10	22

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT