



CODING TABLE

IAC VOR RWY 32					GOIÂNIA / Santa Genoveva, INTL (SBGO)							SBGO_IAC_00I		31 OCT 24	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	UKBIK	IF	N/A	N/A	N/A	+7000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	GNV	GNV03*	AF	N/A	L	N/A	+5500	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	GNV	TIKDU	CF	314.31° Mag 293.70° True	N/A	N/A	+5500	N/A	N/A	1.08	N/A	IF	N/A
10	APCH	N/A	N/A	EDSOS	IF	N/A	N/A	N/A	+7000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	GNV	TIKDU	CF	314.31° Mag 293.70° True	N/A	N/A	+5500	N/A	N/A	5.00	N/A	IF	N/A
10	APCH	N/A	N/A	ANDOS	IF	N/A	N/A	N/A	+7000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	GNV	GNV03*	AF	N/A	R	N/A	+5500	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	GNV	TIKDU	CF	314.31° Mag 293.70° True	N/A	N/A	+5500	N/A	N/A	1.08	N/A	IF	N/A
10	FINAL	N/A	N/A	TIKDU	IF	N/A	N/A	N/A	+5500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	GNV	ARPET	CF	314.31° Mag 293.70° True	N/A	N/A	+4100	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	GNV	GNV04*	CF	314.31° Mag 293.70° True	N/A	N/A	R3458	N/A	N/A	2.00	-3.00	SDF	N/A
40	FINAL	N/A	GNV	GNV22*	CF	314.31° Mag 293.70° True	N/A	N/A	@2503	N/A	N/A	3.00	-3.00	FTP	N/A
10	MA	N/A	GNV	N/A	CA	314.31° Mag 293.70° True	N/A	N/A	+4800	170	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	N/A	VI	140.00° Mag 118.41° True	L	N/A	N/A	170	-	N/A	N/A	OTHER	N/A
30	MA	N/A	GNV	UKBIK	CF	206.63° Mag 186.03° True	R	N/A	+7000	N/A	N/A	N/A	N/A	MAHF	N/A
40	MA	N/A	GNV	UKBIK	HM	26.63° Mag 6.03° True	L	N/A	+7000	N/A	N/A	1.00 min	N/A	MAHF	N/A

*Fictitious point: Only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
UKBIK	S 16:49:27.18W 49:13:39.97
GNV03	S 16:42:42.13W 49:02:05.44
TIKDU	S 16:42:17.18W 49:03:07.70
EDSOS	S 16:44:13.01W 48:58:19.14
ANDOS	S 16:36:24.42W 49:01:24.49
ARPET	S 16:40:21.23W 49:07:56.17
GNV04	S 16:39:34.82W 49:09:51.52
GNV22	S 16:38:25.17W 49:12:44.53

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT