



CODING TABLE

IAC ILS W or LOC W RWY 06				SÃO LUÍS / Marechal Cunha Machado, INTL (SBSL)								SBSL_IAC_00H		04 NOV 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	GUVAB	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	SLI	UDEVU	AF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	IF	N/A
10	APCH	N/A	N/A	VURNI	IF	N/A	N/A	N/A	+4000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	SLI	UDEVU	AF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	IF	N/A
10	FINAL	N/A	N/A	UDEVU	IF	N/A	N/A	N/A	+2500	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N/A	ISL	GEKID	CF	59.94° Mag / 39.04° True	N/A	N/A	R1660	N/A	N/A	5.00	N/A	FAF	N/A
30	FINAL	N/A	ISL	SL039*	CF	59.94° Mag / 39.04° True	N/A	N/A	@223	N/A	N/A	4.50	-3.00	LTP	N/A
10	MA	N/A	ISL	N/A	CA	59.95° Mag / 39.04° True	N/A	N/A	+1300	220	-	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	N/A	VI	239.89° Mag / 219.00° True	L	N/A	+4000	220	-	N/A	N/A	OTHER	N/A
30	MA	N/A	SLI	GUVAB	CF	284.91° Mag / 264.00° True	R	N/A	+4000	220	-	N/A	N/A	MAHF	N/A
40	MA	N/A	SLI	GUVAB	HM	104.91° Mag / 84.00° True	R	N/A	+4000	N/A	N/A	N/A	N/A	MAHF	N/A

(*)Fictitious point only for coding purpose

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
SLI	S 02:35:21.27W 44:14:23.89
ISL	S 02:34:42.01W 44:13:42.11
GUVAB	S 02:36:24.23W 44:24:19.93
UDEVU	S 02:43:14.35W 44:20:35.26
VURNI	S 02:45:20.70W 44:13:21.23
GEKID	S 02:39:20.20W 44:17:26.43
SL039	S 02:35:49.46W 44:14:36.49

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT