CODING TABLE

SID RNAV SAMLU 1A RWY 26					BOA VISTA / Atlas Brasil Cantanhede, INTL (SBBV)							SBBV_SID_00W		16 APR 26	
Seq Num	**Transition Identifier**	**Fly Over**	**Rec Navaid**	**Fix Ident**	**Path and Terminator**	**Course Angle**	**Turn**	**Upper Limit Altitude (FT)**	**Lower Limit Altitude (FT)**	**Speed Limit (KT)**	**Speed Limit Description**	**TM DST (NM)**	**VA (º)**	**Role of the Fix**	**Navigation Specification**
10	RWY	Y	N/A	SAMLU	CF	258.57° Mag 242.43° True	N/A	N/A	N/A	N/A	N/A	3.00	N/A	OTHER	RNAV 1 *or* RNP 1
10	EDSEX	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	EDSEX	N	N/A	EDSEX	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
10	ANBIX	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	ANBIX	N	N/A	ANBIX	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
10	KIGOX	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	KIGOX	N	N/A	KIGOX	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
10	DIVRA	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	DIVRA	N	N/A	DIVRA	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
10	ILNER	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	ILNER	N	N/A	ILNER	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
10	PICOM	N/A	N/A	SAMLU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	PICOM	N	N/A	PICOM	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
SAMLU	N 02:49:04.80W 60:44:43.20
EDSEX	S 03:08:19.21W 61:29:24.59
ANBIX	N 02:11:06.60W 60:37:23.40
KIGOX	N 02:16:01.80W 60:23:54.60
DIVRA	N 03:39:38.40W 60:59:18.00
ILNER	N 03:52:16.20W 60:46:45.60
PICOM	N 03:24:33.60W 60:19:01.80

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
26	N 02:50:26.93 W 60:42:03.05	261.12

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE