CODING TABLE

STAR RNAV DIVRO 1A RWY 28/33					RIO DE JANEIRO / Galeão – Antônio Carlos Jobim, INTL (SBGL)							SBGL_STAR_01V		24 DEC 26	
Seq Num	**Transition Identifier**	**Fly Over**	**Rec Navaid**	**Fix Ident**	**Path and Terminator**	**Course Angle**	**Turn**	**Upper Limit Altitude (FT)**	**Lower Limit Altitude (FT)**	**Speed Limit (KT)**	**Speed Limit Description**	**TM DST (NM)**	**VA (°)**	**Role of the Fix**	**Navigation Specification**
10	MOLSU	N/A	N/A	MOLSU	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	MOLSU	N	N/A	GL034*	TF	232.72° Mag 209.53 True	N/A	N/A	+8000	N/A	N/A	47.30	N/A	OTHER	RNAV 1 *or* RNP 1
30	MOLSU	N	N/A	DIVRO	TF	232.72° Mag 209.56 True	N/A	N/A	N/A	N/A	N/A	9.00	N/A	OTHER	RNAV 1 *or* RNP 1
10	ADA	N/A	N/A	ADA	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	ADA	N	N/A	DIVRO	TF	308.49° Mag 285.33 True	N/A	N/A	N/A	N/A	N/A	34.90	N/A	OTHER	RNAV 1 *or* RNP 1
10	COMMON	N/A	N/A	DIVRO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	COMMON	N	N/A	GL036*	TF	277.69° Mag 254.55 True	N/A	-7000	N/A	N/A	N/A	4.40	N/A	OTHER	RNAV 1 *or* RNP 1
10	RWY28	N/A	N/A	GL036*	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	RWY28	N	N/A	KETUX	TF	277.70° Mag 254.56 True	N/A	N/A	+5000	N/A	N/A	9.71	N/A	IAF	RNAV 1 *or* RNP 1
10	RWY33	N/A	N/A	GL036*	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1
20	RWY33	N	N/A	KETUX	TF	277.72° Mag 254.62 True	N/A	N/A	+5000	N/A	N/A	9.71	N/A	IAF	RNAV 1 *or* RNP 1
30	RWY33	N	N/A	OPSID	TF	234.17° Mag 211.12 True	N/A	N/A	+5000	N/A	N/A	9.93	N/A	IAF	RNAV 1 *or* RNP 1
40	RWY33	N	N/A	N/A	FM	150.00° Mag 126.97° True	N/A	N/A	+5000	N/A	N/A	N/A	N/A	OTHER	RNAV 1 *or* RNP 1

*Fictitious point only for coding purposes.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MOLSU	S 21:50:23.40W 42:12:17.40
VOR/DME ADA	S 22:48:45.99W 42:05:43.22
DIVRO	S 22:39:34.42W 42:42:08.78
KETUX	S 22:43:20.40W 42:56:51.60
OPSID	S 22:51:52.15W 43:02:24.59
GL036*	S 22:40:45.01 W 42:46:43.91
GL034*	S 22:31:43.04 W 42:37:20.99

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT