CODING TABLE

IAC NDB RWY 05					JAGUARUNA / Regional Sul (SBJA)							SBJA_IAC_00G		21 APR 22	
Seq Num	**Transition Identifier**	**Fly Over**	**Rec Navaid**	**Fix Ident**	**Path and Terminator**	**Course Angle**	**Turn**	**Upper Limit Altitude (FT)**	**Lower Limit Altitude (FT)**	**Speed Limit (KT)**	**Speed Limit Description**	**TM DST (NM)**	**VA (°)**	**Role of the Fix**	**Navigation Specification**
10	FINAL	N/A	N/A	JGN	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	JGN	JGN	FC	195.56° Mag / 176.61° True	N/A	N/A	+1500	N/A	N/A	2.00 min	N/A	OTHER	N/A
30	FINAL	N/A	JGN	JGN	CF	42.68° Mag / 23.71° True	R	N/A	@160	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	JGN	N/A	CA	53.71° Mag / 34.68° True	N/A	N/A	+1200	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	JGN	DF	N/A	R	N/A	+3000	220	-	N/A	N/A	MAHF	N/A
30	MA	N/A	JGN	JGN	HM	222.68° Mag / 203.71° True	L	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB JGN	S 28:40:43.86W 49:04:00.17

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT