



CODING TABLE

IAC NDB RWY 16					MAXARANGUAPE / Maxaranguape, MIL (SNXX)							SNXX_IAC_00B		26 JAN 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	MXN	MXN	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	MXN	MXN	FC	4.57° Mag 343.9° True	N/A	N/A	+2000	-200	N/A	2.67min	N/A	OTHER	N/A
30	APCH	N/A	MXN	KOSRI	CF	167.60° Mag 147.00° True	L	N/A	R1930	N/A	N/A	N/A	N/A	FAF	N/A
10	FINAL	N/A	MXN	KOSRI	IF	N/A	N/A	N/A	R1930	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	MXN	XX012*	CF	168.60° Mag 147.00° True	N/A	N/A	@336	N/A	N/A	5.00	-3.00	FTP	N/A
10	MA	N/A	MXN	N/A	CA	167.60° Mag 147.00° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	MA	N/A	N/A	MXN	DF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	MXN	MXN	HM	4.80° Mag 344.10° True	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A

(*) Fictitious point only for coding purpose

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB MXN	S 05:23:10.20W 35:31:51.60
XX012	S 05:22:40.20W 35:32:11.07
KOSRI	S 05:18:27.49W 35:34:55.06

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT