



## CODING TABLE

IAC ILS W or LOC W RWY 16L					NATAL / Campo Augusto Severo, MIL (SBNT)							SBNT_IAC_01D		15 MAY 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	NTL	EGEGI	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	NTL	IRUNU	AF	N/A	R	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
30	APCH	N/A	NTL	OPNAG	AF	N/A	R	N/A	+2000	180	-	N/A	N/A	OTHER	N/A
10	FINAL	N/A	NTL	OPNAG	IF	N/A	N/A	N/A	+2000	180	-	N/A	N/A	IF	N/A
20	FINAL	N/A	INT	BUXUP	CF	161.71° Mag 141.00° True	N/A	N/A	+1800	N/A	N/A	2.59	N/A	FAF	N/A
30	FINAL	N/A	INT	NT003*	CF	161.81° Mag 141.10° True	N/A	N/A	R872	N/A	N/A	2.90	-3.00	SDF	N/A
40	FINAL	N/A	INT	RW16L	CF	161.81° Mag 141.10° True	N/A	N/A	@203	N/A	N/A	2.10	-3.00	LTP	N/A
10	MA	N/A	N/A	N/A	VD	161.71° Mag 141.00° True	N/A	N/A	N/A	N/A	N/A	8.00	N/A	OTHER	N/A
20	MA	N/A	NTL	EGEGI	AF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	NTL	EGEGI	HM	59.31° Mag 388.61° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

\* Fictitious point: Only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
EGEGI	S 06:00:46.96W 35:19:55.88
IRUNU	S 05:51:12.31W 35:22:14.47
OPNAG	S 05:48:11.04W 35:19:53.13
BUXUP	S 05:50:12.28W 35:18:15.12
NT003	S 05:52:28.16W 35:16:25.26
RW16L	S 05:54:06.60W 35:15:05.70

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT