



CODING TABLE

IAC VOR RWY 08					MACAPÁ / Alberto Alcolumbre, INTL (SBMQ)							SBMQ_IAC_00F		21 APR 22	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	APCH	N/A	N/A	MCP	IF	N/A	N/A	N/A	+3000	N/A	N/A	N/A	N/A	IAF	N/A
20	APCH	N/A	MCP	MCP	FC	278.63° Mag 259.21° True	N/A	N/A	+1700	230	-	8.00	N/A	OTHER	N/A
30	APCH	N/A	MCP	DADOS	CF	71.88° Mag 52.45° True	L	N/A	R1690	N/A	N/A	2.42	N/A	FAF	N/A
10	FINAL	N/A	N/A	DADOS	IF	N/A	N/A	N/A	R1690	N/A	N/A	N/A	N/A	FAF	N/A
20	FINAL	N/A	MCP	MQ001*	CF	71.88° Mag 52.45° True	N/A	N/A	@99	N/A	N/A	5.00	-3.00	FTP	N/A
10	MA	N/A	MCP	N/A	CA	71.88° Mag 52.45° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	MAHF	N/A
20	MA	N/A	N/A	MCP	DF	N/A	R	N/A	+3000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	MCP	MCP	HM	278.64° Mag 259.21° True	R	N/A	+3000	N/A	N/A	1.00 min	N/A	MAHF	N/A

* Fictitious point only for coding purpose.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
MCP	N 00:03:08.15W 51:04:23.01
DADOS	S 00:00:16.79W 51:08:47.95
MQ001	N 00:02:46.95W 51:04:50.53

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT