



## CODING TABLE

SID RNAV PULUR 2A RWY 30					ARACAJU / Santa Maria, INTL (SBAR)							SBAR_SID_00K		06 AUG 26	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	RWY	Y	N/A	PULUR	CF	294.32° Mag 271.97° True	N/A	N/A	N/A	N/A	N/A	3.84	2.29	OTHER	RNAV 1 or RNP 1
10	ANDIG	N/A	N/A	PULUR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ANDIG	N	N/A	AR002	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	ANDIG	N	N/A	ANDIG	TF	64.11° Mag 41.81° True	N/A	N/A	N/A	N/A	N/A	53.02	N/A	OTHER	RNAV 1 or RNP 1
10	DENDO	N/A	N/A	PULUR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	DENDO	N	N/A	AR002	DF	N/A	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	DENDO	N	N/A	DENDO	TF	73.57° Mag 51.26° True	N/A	N/A	N/A	N/A	N/A	54.06	N/A	OTHER	RNAV 1 or RNP 1
10	DABAD	N/A	N/A	PULUR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	DABAD	N	N/A	ISRUB	DF	N/A	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
30	DABAD	N	N/A	DABAD	TF	271.77° Mag 249.29° True	N/A	N/A	N/A	N/A	N/A	41.04	N/A	OTHER	RNAV 1 or RNP 1
10	ARURU	N/A	N/A	PULUR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ARURU	N	N/A	ARURU	TF	231.50° Mag 209.14° True	N/A	N/A	N/A	N/A	N/A	65.71	N/A	OTHER	RNAV 1 or RNP 1
10	AKNUT	N/A	N/A	PULUR	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	AKNUT	N	N/A	AKNUT	TF	190.86° Mag 168.51° True	N/A	N/A	N/A	N/A	N/A	82.26	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
PULUR	S 10:58:52.95W 37:08:53.55
AR002	S 10:48:50.57W 37:08:32.41
ANDIG	S 10:09:06.55W 36:32:42.10
DENDO	S 10:14:48.60W 36:25:46.20
ISRUB	S 11:14:52.18W 37:42:20.68
DABAD	S 11:29:24.42W 38:21:26.25
ARURU	S 11:56:30.40W 37:41:32.20
AKNUT	S 12:19:51.20W 36:52:09.17

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
30	S 10:59:01.26 W 37:04:49.47	23.00

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT