



## CODING TABLE

IAC ILS V RWY 35L				SÃO PAULO / Congonhas, INTL (SBSP)								SBSP_IAC_00Q		20 MAY 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit(KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role Of The Fix	Navigation Specification
10	APCH	N/A	N/A	NAXUP	IF	N/A	N/A	N/A	+6000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	USITO	TF	328.21° Mag 306.64° True	N/A	N/A	+5300	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	APCH	N/A	N/A	OGTAL	IF	N/A	N/A	N/A	+6000	N/A	N/A	N/A	N/A	IAF	RNAV 1 or RNP 1
20	APCH	N	N/A	USITO	TF	73.29° Mag 51.72° True	N/A	N/A	+5300	N/A	N/A	6.00	N/A	IF	RNAV 1 or RNP 1
10	FINAL	N/A	N/A	USITO	IF	N/A	N/A	N/A	+5300	N/A	N/A	N/A	N/A	IF	N/A
20	FINAL	N	ISO	SURBU	CF	349.04° Mag 327.48° True	N/A	N/A	R4290	N/A	N/A	6.32	N/A	FAF	N/A
30	FINAL	N	ISO	RW35L	CF	349.05° Mag 327.50° True	N/A	N/A	@2689	N/A	N/A	5.03	-3.00	LTP/FTP	N/A
10	MA	N/A	N/A	N/A	CA	349.03° Mag 327.48° True	N/A	N/A	+3500	N/A	N/A	N/A	2.49	N/A	RNAV 1 or RNP 1
20	MA	Y	N/A	OGTAL	DF	N/A	L	N/A	+6000	N/A	N/A	N/A	N/A	MAHF	RNAV 1 or RNP 1
30	MA	Y	N/A	OGTAL	HM	073.29° Mag 051.72° True	R	N/A	+6000	N/A	N/A	N/A	N/A	MAHF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NAXUP	S 23:51:15.00W 46:27:10.20
OGTAL	S 23:51:23.29W 46:37:33.47
USITO	S 23:47:39.60W 46:32:25.20
SURBU	S 23:42:18.89W 46:36:07.42
RWY35L	S 23:38:03.49W 46:39:04.27
ISO	S 23:37:09.60W 46:39:41.40

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT.