



## CODING TABLE

SID VUPOM 1A RWY 11					MANAUS / Eduardo Gomes, INTL (SBEG)							SBEG_SID_02A		20 FEB 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	VUPOM	N/A	N/A	N/A	VA	106.14° Mag 90.12° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	VUPOM	N/A	N/A	MNS	DF	N/A	L	N/A	+5000	N/A	N/A	N/A	N/A	OTHER	N/A
30	VUPOM	N/A	MNS	VUPOM	CF	278.72° Mag 263.70° True	N/A	N/A	N/A	N/A	N/A	24.22	N/A	OTHER	N/A

SID AKRUT 1A RWY 11					MANAUS / Eduardo Gomes, INTL (SBEG)							SBEG_SID_02A		20 FEB 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	AKRUT	N/A	N/A	N/A	VA	106.14° Mag 90.12° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	AKRUT	N/A	MNS	AKRUT	CF	111.52° Mag 95.51° True	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

SID SIPOX 1A RWY 11					MANAUS / Eduardo Gomes, INTL (SBEG)							SBEG_SID_02A		20 FEB 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	SIPOX	N/A	N/A	N/A	VA	106.14° Mag 90.12° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	SIPOX	N/A	N/A	N/A	VI	316.09° Mag 300.00° True	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	SIPOX	N/A	MNS	SIPOX	CF	4.63° Mag 348.63° True	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
VOR/DME MNS	S 03:02:24.11W 60:03:17.06
VUPOM	S 03:05:04.00W 60:27:21.00
AKRUT	S 03:04:48.60W 59:38:24.60
SIPOX	S 02:22:12.60W 60:11:19.20

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
11	S 03:02:19.02 W 60:02:15.19	263.45

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT