



CODING TABLE

SID MASDU 1A RWY 09					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_SID_01V		23 FEB 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	MASDU	N/A	N/A	N/A	VA	92.64° Mag / 76.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	MASDU	N/A	PEL	MASDU	CF	96.69° Mag / 79.99° True	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

SID SIPOX 1A RWY 09					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_SID_01V		23 FEB 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	SIPOX	N/A	N/A	N/A	VA	92.64° Mag / 76.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	SIPOX	N/A	N/A	N/A	VI	326.48° Mag / 310.00° True	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	SIPOX	N/A	PEL	SIPOX	CF	2.17° Mag / 345.77° True	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

SID VUPOM 1A RWY 09					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_SID_01V		23 FEB 23	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	VUPOM	N/A	N/A	N/A	VA	92.64° Mag / 76.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	VUPOM	N/A	N/A	PEL	DF	N/A	R	N/A	+5000	N/A	N/A	N/A	N/A	OTHER	N/A
30	VUPOM	N/A	PEL	VUPOM	CF	293.44° Mag / 277.18° True	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB PEL	S 03:08:34.20W 59:59:37.80
MASDU	S 03:04:48.60W 59:38:24.60
SIPOX	S 02:22:12.60W 60:11:19.20
VUPOM	S 03:05:04.00W 60:27:21.00

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
09	S 03:08:38.13 W 59:58:40.64	250.00

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT