



CODING TABLE

SID VUPOM 1B RWY 27					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_SID_01W		20 FEB 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	VUPOM	N/A	N/A	N/A	VA	272.60° Mag 256.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	VUPOM	N/A	PEL	VUPOM	CF	293.44° Mag 277.15° True	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

SID SIPOX 1B RWY 27					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_SID_01W		20 FEB 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	SIPOX	N/A	N/A	N/A	VA	272.60° Mag 256.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	SIPOX	N/A	N/A	N/A	VI	35.96° Mag 20.00° True	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A
30	SIPOX	N/A	PEL	SIPOX	CF	2.17° Mag 345.76° True	L	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

SID AKRUT 1B RWY 27					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_SID_01W		20 FEB 25	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	AKRUT	N/A	N/A	N/A	VA	272.60° Mag 256.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	OTHER	N/A
20	AKRUT	N/A	N/A	PEL	DF	N/A	L	N/A	+5000	N/A	N/A	N/A	N/A	OTHER	N/A
30	AKRUT	N/A	PEL	AKRUT	CF	96.69° Mag 80.00° True	R	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	N/A

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
NDB PEL	S 03:08:34.09W 59:59:37.55
AKRUT	S 03:04:48.60W 59:38:24.60
SIPOX	S 02:22:12.60W 60:11:19.20
VUPOM	S 03:05:04.00W 60:27:21.00

DER	Latitude / Longitude (WGS84) DD:MM:SS.SS	Elevation (FT)
27	S 03:08:54.12W 59:59:44.82	247.70

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT