



CODING TABLE

STAR RNAV MULSO 1A RWY 11					ILHÉUS / Jorge Amado (SBIL)							SBIL_STAR_00N	14 JUL 22		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	MULSO	N/A	N/A	MULSO	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	MULSO	N	N/A	IL022	TF	77.33° Mag / 53.63° True	N/A	B8000	B4500	N/A	N/A	51.88	N/A	OTHER	RNAV 1 or RNP 1
30	MULSO	N	N/A	IL018	TF	76.66° Mag / 52.93° True	N/A	N/A	+4000	N/A	N/A	17.67	N/A	IAF	RNAV 1 or RNP 1

STAR RNAV TOLOG 1A RWY 11					ILHÉUS / Jorge Amado (SBIL)							SBIL_STAR_00N	14 JUL 22		
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	TOLOG	N/A	N/A	TOLOG	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	TOLOG	N	N/A	IL021	TF	231.20° Mag / 207.58° True	N/A	-8000	N/A	N/A	N/A	43.79	N/A	OTHER	RNAV 1 or RNP 1
30	TOLOG	N	N/A	IL017	TF	231.36° Mag / 207.66° True	N/A	N/A	+4000	N/A	N/A	17.43	N/A	IAF	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
IL017	S 14:44:13.35W 39:12:52.53
IL018	S 14:49:22.61W 39:17:53.75
MULSO	S 15:31:03.00W 40:15:36.60
IL021	S 14:28:43.66W 39:04:31.35
IL022	S 15:00:04.90W 39:32:27.00
TOLOG	S 13:49:45.40W 38:43:36.60

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT