



CODING TABLE

IAC NDB RWY 09					MANAUS / Ponta Pelada, MIL (SBMN)							SBMN_IAC_00H		04 NOV 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	FINAL	N/A	N/A	PEL	IF	N/A	N/A	N/A	+2000	N/A	N/A	N/A	N/A	IAF	N/A
20	FINAL	N/A	PEL	PEL	FC	284.94° Mag / 268.91° True	N/A	N/A	+1500	250	-	2.00 min	N/A	IAF	N/A
30	FINAL	N/A	PEL	PEL02*	CF	77.12° Mag / 61.08° True	L	N/A	@298	N/A	N/A	N/A	N/A	FTP	N/A
10	MA	N/A	PEL	N/A	CA	77.12° Mag / 61.08° True	N/A	N/A	+2000	N/A	N/A	N/A	N/A	N/A	N/A
20	MA	N/A	N/A	PEL	DF	N/A	R	N/A	+2000	N/A	N/A	N/A	N/A	MAHF	N/A
30	MA	N/A	PEL	PEL	HM	284.95° Mag / 268.91° True	L	N/A	+2000	N/A	N/A	1.00 min	N/A	MAHF	N/A

* Fictitious point = for coding purpose only.

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
PEL	S 03:08:34.17W 59:59:37.49
PEL02	S 03:08:41.07W 59:59:49.92

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT