



## CODING TABLE

STAR RNAV DOSPI 1B RWY 35R/35L					SÃO PAULO / Congonhas (SBSP)							SBSP_STAR_01Z		20 MAY 21	
Seq Num	Transition Identifier	Fly Over	Rec Navaid	Fix Ident	Path and Terminator	Course Angle	Turn	Upper Limit Altitude (FT)	Lower Limit Altitude (FT)	Speed Limit (KT)	Speed Limit Description	TM DST (NM)	VA (°)	Role of the Fix	Navigation Specification
10	UTLOT	N	N/A	UTLOT	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	UTLOT	N	N/A	IREMA	TF	145.80° Mag 124.48° True	N/A	-24000	+20000	N/A	N/A	22.82	N/A	OTHER	RNAV 1 or RNP 1
30	UTLOT	N	N/A	SP109	TF	145.80° Mag 124.43° True	N/A	N/A	N/A	N/A	N/A	10.01	N/A	OTHER	RNAV 1 or RNP 1
40	UTLOT	N	N/A	DOSPI	TF	145.80° Mag 124.35° True	N/A	N/A	N/A	N/A	N/A	15.36	N/A	OTHER	RNAV 1 or RNP 1
10	ENTIT	N	N/A	ENTIT	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	ENTIT	N	N/A	SP092	TF	244.85° Mag 223.13° True	N/A	N/A	N/A	N/A	N/A	5.96	N/A	OTHER	RNAV 1 or RNP 1
30	ENTIT	N	N/A	SP093	TF	244.83° Mag 223.16° True	N/A	-24000	N/A	N/A	N/A	5.15	N/A	OTHER	RNAV 1 or RNP 1
40	ENTIT	N	N/A	SP094	TF	244.77° Mag 223.25° True	N/A	N/A	+21000	N/A	N/A	22.06	N/A	OTHER	RNAV 1 or RNP 1
50	ENTIT	N	N/A	DOSPI	TF	244.63° Mag 223.19° True	N/A	N/A	N/A	N/A	N/A	8.87	N/A	OTHER	RNAV 1 or RNP 1
10	RWY	N	N/A	DOSPI	IF	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1
20	RWY	N	N/A	SP096	TF	190.06° Mag 168.62° True	N/A	B17000	B13000	N/A	N/A	5.74	N/A	OTHER	RNAV 1 or RNP 1
30	RWY	N	N/A	SP097	TF	189.90° Mag 168.48° True	N/A	N/A	+10000	N/A	N/A	13.51	N/A	OTHER	RNAV 1 or RNP 1
40	RWY	N	N/A	IROPU	TF	189.95° Mag 168.55° True	N/A	N/A	N/A	N/A	N/A	10.95	N/A	OTHER	RNAV 1 or RNP 1
50	RWY	N	N/A	KOMGU	TF	143.77° Mag 122.28° True	N/A	N/A	@9000	N/A	N/A	15.65	N/A	OTHER	RNAV 1 or RNP 1
60	RWY	N	N/A	SP098	TF	168.95° Mag 147.45° True	N/A	N/A	@9000	N/A	N/A	5.58	N/A	OTHER	RNAV 1 or RNP 1
70	RWY	N	N/A	OGTAL	TF	168.92° Mag 147.40° True	N/A	N/A	+6000	N/A	N/A	15.07	N/A	IAF	RNAV 1 or RNP 1
80	RWY	N	N/A	N/A	VM	170.00° Mag 148.48° True	N/A	N/A	+6000	N/A	N/A	N/A	N/A	OTHER	RNAV 1 or RNP 1

Ident	Latitude / Longitude (WGS84) DD:MM:SS.SS
UTLOT	S 22:28:26.40W 47:53:32.40
IREMA	S 22:41:25.38W 47:33:13.83
SP109	S 22:47:06.49W 47:24:17.96
ENTIT	S 22:25:03.04W 46:39:28.71
SP092	S 22:29:24.97W 46:43:52.60
SP093	S 22:33:11.27W 46:47:40.90
SP094	S 22:49:19.29W 47:04:00.63
DOSPI	S 22:55:48.73W 47:10:34.80
SP096	S 23:01:27.85W 47:09:21.08
SP097	S 23:14:45.08W 47:06:25.55
IROPU	S 23:25:31.05W 47:04:03.91
KOMGU	S 23:33:54.89W 46:49:40.64
SP098	S 23:38:38.80W 46:46:24.07
OGTAL	S 23:51:23.29W 46:37:33.47

COD	Meaning
+	AT OR ABOVE
-	AT OR BELOW
@	AT
R	RECOMMENDED
B	BETWEEN
=	AS ASSIGNED
SDF	STEPDOWN FIX
Y	YES
N	NO
L	LEFT
R	RIGHT
N/A	NOT APPLICABLE
LTP	LANDING THRESHOLD POINT
FTP	FICTITIOUS THRESHOLD POINT.